

Installation and Precaution.

- It is important not to install the equipment directly exposed to sea water.
- Avoid sandy location i.e. near the shore.
- Select a well-drained location.
- Extra care is required during hoisting and handling the equipment to prevent scratches on the protection coating.
- No sharp material to be use during handling.
- Clear all unwanted debris/drilling particles on the bottom frame
- For prolong storage at site before operation, do protect the equipment with existing packaging box prior to handing over.
- In situation where the unit is installed close to coastal area and expose to strong sea breeze, it is important to install a windbreaker/retaining wall to prolong the life span of the equipment protection coating.

